

Garden Trading®

Stowe Parcel Box Assembly Instructions

Please read through these instructions and ensure they are kept for future reference.



Fixing Instructions

1. Open the front of the post box and mark the 4 screw holes with a pencil.
2. Drill 4 holes 30-35mm deep in the marked areas.
3. Hammer in supplied wall plugs.
4. Align post box with the wall plugs and drill screws through the post box and into the wall plugs.
5. To lock the parcel box, the lock on the side needs to be pushed in. To unlock, use the keys provided to twist and pull the lock back out.

gardentrading.co.uk

+44 (0)1993 845 559

customerservices@gardentrading.co.uk

Opening Hours: Monday - Friday: 8.30am - 5.30pm (Friday close at 5.00pm)

The Garden Trading Company Ltd, Carterton South Industrial Estate, Black Bourton Road, Carterton, Oxon, OX18 3EZ



IIPBCO13/01